



www.imoticondrives.co.uk

Document number	Imoticon-ID700-003
Revision	0.0
Author	Gareth Lloyd
Product	Imoticon ID700
Title	Imoticon ID700 Password (Security Code)
Summary	This document gives information on how to set a password (security code) into the Imoticon ID700 and also how to reset the password if the password gets forgotten

NOTE: Please read this document in conjunction with the Imoticon ID700 Easy Start Guide and Imoticon ID700 Advanced User Manual.

Setting a password into the Imoticon ID700 can stop unwanted changes to parameters after a set-up has been implemented into the inverter.

As default, the security code set in parameter P00.22 is set to 0 – password disabled. All parameters can be accessed and adjusted.

Setting a password (security code)

Power up the Imoticon ID700

Press the PRG button so that P00.01 is on the drives display

Press the UP or DOWN button until parameter P00.22 is shown on the display

Press the PRG button so '0' is flashing on the display

Press the UP button to the desired password

Press the PRG button

Press the ESC button

The password is now set within the drive.

Before any parameters can be viewed to changed, the password must be entered into parameter P00.22

Entering a password

If a password has already been set:

Press the PRG button

P00.22 is shown on the display

Press the PRG button

'0' is flashing on the display

Enter the correct password

Press the PRG button

P00.01 is shown on the display

The password has now been entered correctly so parameters can be viewed and changed.

Resetting a password to '0' – no password

Press the PRG button

P00.22 is shown on the display

Press the PRG button

'0' is flashing on the display

Enter the correct password

Press the PRG button

P00.01 is shown on the display

Press the UP or DOWN button until parameter P00.22 is shown on the display

Press the PRG button so that the current password is flashing on the display

Set P00.22 to '0' and press the PRG button

The password is now reset to '0'

Resetting a forgotten password

Power down the Imoticon ID700

Press the PRG, UP and STOP buttons and power up the Imoticon ID700

The password will be reset to '0' and all parameters can be viewed and changed

NOTE: This will not set default parameters within the drive, this just resets the password to '0'